# Series W-WGR11-L

## PN16 Grooved Type Buttefly Valve with Lever Handle

## Series W-WGR11-G

## **PN16 Grooved Type Buttefly Valve with Gearbox**

## Size: DN80-DN150(-L) DN80-DN200(-G)

Potable water service Butterfly Valves with Watermark certification, for on and off flow control service. Suitable applications would include building services, water and wastewater, general industry, and irrigation water supply.

#### **Features**

- Quality robust construction
- Excellent sealing due to unique disk and seat contour
- Single piece 316SS shaft eliminating potential pin and bolt leakages
- Position indicators

#### **Pressure - Temperature**

- Nominal Pressure: PN16
- $\bullet$  Working Temperature: -20  $^\circ\!\mathrm{C}$  ~+120  $^\circ\!\mathrm{C}$

## **Material**

Component	Material
Body	Ductile Iron
Disc	Ductile Iron + EPDM
Stem	Stainless Steel
Seat	EPDM

## **Installation Dimensions**




## **Specification**


- Design Standard: ATS 5200.012-2005
- Test Standard: ISO 5208-2008
- Connection Type: Groove End
- Connection Standard: ANSI / AWWA C606-06
- Working Medium: Non corrosive liquids
  - Maximum 30% glycol/water mix


#### **Approvals**


• Water Mark License No.: WMK 26060











Ŧ

A	Contour Dimension (mm)				End Connection Dimension (mm)				End Connection Dimension (mm)							
									H4	H5		ФЕ				
	H1	H2	ΦD	L1	ΦOD	ФС	А	В	ΦЕ	114	113		Туре	ΦD6	ΦD4	n×d
80	95	181	105	97	88.9	84.9	15.9	7.9	77.7	24	14	□9	F07	92	70	4×φ10
100	114	200	132	116	114.3	110	15.9	9.5	101.2	26	14	□11	F07	92	70	4×φ10
150	139	226	185	148	165.1	160.8	15.9	9.5	150.5	26	14	□14	F07	92	70	4×φ10
200	175	260	239	134	219.1	214.4	19.1	11.1	203.2	33	14	□17	F10	125	102	4×φ12

DN	Lever Ope	rated Blue	Gear Operated Blue				
DN	H3	L	H3	ΦF	L		
80	32	267	66	150	160		
100	32	267	66	150	160		
150	32	267	66	150	160		
200	/	/	82	298	240		

Watts reserves the right to change or modify product design, construction, specifications, or materials without prior notice and without incurring any obligation to make such changes and modifications on Watts products previously or subsequently sold.



## Installation Instructions

- 1. Compare the rated parameters of the equipment with the rated parameters marked on product, ensure that products meet the requirements of the application.
- 2. Installation personnel should be trained and experienced, to ensure that the installation is completed correctly.
- 3. At the end of the installation, check thoroughly to make sure it is installed correctly.
- 4. In order to ensure the installation work does not cause an accident or operation issue, thoroughly clean the pipe system before the product installation (using chemical reagent if it is necessary). To ensure that the pipeline system is clean of, no corrosion and no dirt, additionally remove all the filters before washing to ensure that the pipeline is unblocked and clean. Advice is to install temporary pipeline in place of device within the installation, then install the equipment into the pipeline after finishing the cleaning work.
- 5. Notice that the devices must not be used in the applications where the medium is containing a higher viscosity such as oil, mineral oil or is a corrosive medium.
- 6. If testing the device use the standard nominal connections.

Watts reserves the right to change or modify product design, construction, specifications, or materials without prior notice and without incurring any obligation to make such changes and modifications on Watts products previously or subsequently sold.

